

# Service Manual Indicator *PWH3*



© Excell Precision Limited 2015. All rights reserved Worldwide.

The information contained herein is the property of Excell Precision Limited and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorised by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.



# Table of Contents

SPECIAL NOTICE ..... 3

BEFORE USING THE SCALE ..... 4

INSTRUCTIONS FOR USE ..... 4

PREPARING TO USE THE SCALE ..... 4

QUICK SETUP CALIBRATION ..... 6

CHAPTER 1 INTRODUCTION ..... 7

    1-1 Product Features..... 7

    1-2 Specifications ..... 7

    1-3 Product Appearance..... 7

    1-4 Display Description ..... 8

    1-5 Power Supply ..... 9

    1-6 Keypad Function ..... 9

    1-7 Self-Test Mode ..... 11

    1-8 Error Messages..... 12

    1-9 Weight Units..... 12

CHAPTER 2 CONFIGURATIONS..... 13

CONFIGURATION WORKFLOW..... 13

    2-1 General Function Setting 01 Fnc ..... 14

        2-1-1 Auto Backlight Function Setting Fnc 01 ..... 15

        2-1-2 Auto Power-off Timer Setting Fnc 02 ..... 16

        2-1-3 HI/LO/OK Settings Fnc 03 ..... 17

        2-1-4 Restore to the Default Settings Fnc 04 ..... 18

        2-1-5 Noise Filter Settings Fnc 05 ..... 19

        2-1-6 Hold Function Settings Fnc 06 ..... 20

        2-1-7 Auto Unit Weight Averaging Setting Fnc 07 ..... 22

        2-1-8 Record Last Zero Fnc 10 ..... 22

        2-1-9 Foot Switch Settings Fnc 11 (Option) ..... 23

        2-1-10 [F] Key Function Settings Fnc 12 ..... 24

        2-1-11 Zero Setting Fnc 13 ..... 24

    2-2 External Weight Calibration 02 EC ..... 25

    2-3 RS232 Serial Interface Settings 03 r5 1 ..... 26

        2-3-1 Baud Rate Settings r5 1 01 ..... 27

        2-3-2 Communication Protocol Settings r5 1 02 ..... 28

        2-3-3 Output Format Settings r5 1 03 ..... 29

        2-3-4 Continuous Transmission Settings r5 1 04 ..... 31

        2-3-5 Selection of the Continuous Transmission Rate r5 1 05 ..... 32



2-3-6 Auto Transmission at Zero	r5 1 06	33
2-3-7 Reset Auto Transmission	r5 1 07	34
2-3-8 Output Condition Settings	r5 1 08	35
2-3-9 RS232 6/7 Digits Setting	r5 1 09	36
2-3-10 RTC Adjustment	r5 1 1 0	37
2-3-11 Y/M/D Print Layout Selection	r5 1 1 1	37
2-3-12 RS485 ID Input (Option)	r5 1 1 2	38
2-3-13 Line Feed Input	r5 1 1 3	38
CHAPTER 3 SERVICE MODE ACCESS		39
3-1 Capacity Setup	0 1 CSP	40
3-1-1 Weight Unit Setting	CSP 0 1	41
3-1-2 Customised Capacity Setting	CSP 0 2	44
3-1-3 Multi-segment Setting	CSP 0 3	50
3-2 Linearity Calibration	0 3 CLn	51
3-3 Weight Calibration	0 2 CAL	54
3-3-1 Weight Calibration Setting	CAL 0 1	55
3-3-2 Manufacturing Location Gravity Setting	CAL 0 2	56
3-4 Local Gravity Setting	0 6 CLr	57
3-5 Function Setting	0 4 CFn	58
3-5-1 Environment Parameters	CFn 0 1	59
3-5-2 Approval Configuration	CFn 0 2	60
3-5-3 Initial Zero Setting	CFn 0 4	61
3-5-4 Hold Function Setting	CFn 0 5	62
3-5-5 Zero Tracking	CFn 0 6	64
APPENDIX 1 ASCII CODE TABLE		71
APPENDIX 2 7-SEGMENT DISPLAY CHARACTERS		72
APPENDIX 3 WIRING INSTRUCTIONS		73



## Special Notice


While installing the load cell, power cord hookup or replacing a new rechargeable battery, the indicator housing must be opened. It must be done by a technician assigned by your electronic indicator provider to avoid affecting the waterproof ability of this indicator. Before opening the housing, make sure the indicator is dry, if there is any liquid on it, please wipe it with a clean cloth.

### HOW TO INSTALL THE HOUSING

After installing the load cell, power cord hookup or replacing a new rechargeable battery, the housing must be screwed by the assigned order as shown below. Screw lightly first, then screw them tight using a 12 kgf-cm torsion.

P.s. Please use a torsion-adjustable screw driver.

Screwing order:





Thank you for purchasing EXCELL WEIGHING INDICATOR, to help use the product properly, operate smoothly, and extend its life cycle, please read this manual carefully.


## Before Using the Scale

In order to use this scale correctly, we suggest that you read this manual carefully.

## Instructions for Use

1. The load placed on the weigh pan must NOT exceed the maximum weighing capacity of the scale.
2. Protect the scale from high temperatures.
3. Avoid objects impacting with the scale. Do not drop loads onto the scale or subject the weigh pan to any strong shock loads.
4. Please operate or charge the scale in an open area. Do not squeeze the power cord to avoid wire on fire.

## Preparing to Use the Scale

1. Locate the scale on a firm level surface free from vibrations for accurate weight readings.
2. Adjust the four levelling feet (if fitted) to set the scale pan level.
3. Avoid operating the scale in direct sunlight or drafts of any kind.
4. If possible avoid connecting the scale to ac power outlet sockets which are adjacent to other appliances to minimise the possibility of interference affecting the performance of the scale.
5. Remove any weight that might be on the weigh pan before the scale is switched on and avoid leaving weight on the pan for long periods of time.
6. All goods weighed should be placed in the centre of the weigh pan for accurate weighing. The overall dimensions of the goods being weighed should not exceed the dimension of the weigh pan.
7. Once the scale has been powered on, it will go through an LCD display test and it is ready for use when the display shows zero.
8. The scale requires 15~20 minutes warm up before operation to ensure best accuracy.
9. Please note when the  symbol keeps flashing on the screen, the batteries need to be charged.
10. Introduction of Storage Battery




Due to the storage battery adopt the advanced free-maintaining technique, customers need not to replenish electrolyte.

The scale should be recharged every 3 months to prevent failure of the internal rechargeable battery.

1. The battery should be charged for 8~10 hours.
2. The temperature of battery should below 45°C.

## Maintaining

1. Please do not discharge with over-current when using the battery. Please charge the battery after discharging current.
2. Please take down the battery when the scale is not used for a long time or break the connection of cathode.
3. Do not short the battery terminals to check whether there is current. Please check whether the connection point is firm to guarantee good connection.
4. The battery should be replaced by specialized person. **No reverse-battery or the product will be damaged.**
  - a) Anode of battery should be connected with Anode of product battery ( usually red cable )
  - b) Cathode of battery should be connected with Cathode of product battery (usually brown cable or black cable)
  - c) See the picture following



Brown cable(or black cable) connected with Anode of battery

Red cable connected with Cathode of battery

## Safety warnings

1. The electrolyte of battery is caustic which causes metal, cotton, etc to corrode.
2. The hydrogen will be resolved when using or charging the battery and it will cause explosion when approaches fire.



No burning



Caution Corrosion



Warning explosion



Children faraway



## Quick Setup Calibration

This page is to quickly initiate the scale, for the other functions configuration, you can refer the chapters below.

### Instructions:

#### Step 1 :

- Power off the scale and open the case, find the mini-jumper SWA1 on the main board.
- Switch SWA1 to the ADJ position (EEPROM UNLOCKED) and then turn the power on. The display will show **01 C5P**.

#### Step 2 :

- Refer to the chapter 4-1 at page 40 to complete Capacity Setup.

**01 C5P**

#### Step 3 :

- Refer to the chapter 4-2 at page 51 to complete Linearity Calibration.

**03 CLn**

#### Step 4 :

- Refer to the chapter 4-3 at page 54 to complete Weight Calibration.

**02 CAL**

#### Step 5 :

- When done the initiation, switch the jumper SWA1 back to the LOCK position.

📄 If the jumper SWA1 is switched to the LOCK position during calibration, the machine will exit the service mode automatically.



# Chapter 1 Introduction



## 1-1 Product Features

- Sealed to IP68, (Only use cables of 3mm~5mm diameter to ensure correct sealing of the cable glands)
- Kilogram (kg) and pound (lb) weighing modes
- Full range tare; Pre-tare; Auto zero tracking; Sampling counting; Gross/Net indication
- Adjustable gravity value
- Low power indication and auto power off
- AC/DC power in and rechargeable battery.
- Built-in RS-232
- Options: pressure release valve, foot switch


## 1-2 Specifications

- Analogue Input: Input Sensitivity  $0.3\mu\text{V/d}$  (Min.)
- Input Signal Range:  $-1\text{mV}\sim+14\text{mV}$
- Input Zero Range:  $-1\text{mV}\sim+5\text{mV}$
- Load Cell Excitation: 5V DC
- Load Cell Drive Capacity: Up to 8 x  $350\Omega$  load cells
- Non-linearity: 0.01% of full scale
- A/D Resolution: 500,000 counts (Maximum)
- Operating temperature:  $-10^{\circ}\text{C} \sim 40^{\circ}\text{C}$

## 1-3 Product Appearance








(RS-232 and load cell cables size 3mm~5.5mm diameter to ensure correct sealing of the cable glands)

### 1-4 Display Description



- HI** : Upper limit
- OK** : Value between HI and LO
- LO** : Lower limit
- kg** : Unit “kilogram”
- lb** : Unit “pound”
- t** : hk tael
- Pcs** : Counting mode indication
- 0←** : Zero point indication
- Net** : Net weight indication
- : Low Power indication

**Non-approval model: “▼” indications description**

- ▼1 : (STABLE) stable indication
- ▼2 : (GROSS) gross weight indication
- ▼3 : ( ) unit weight insufficient indication
- ▼4 : ( PT ) pre-tare indication
- ▼5 : (Hold) weight hold indication
- ▼6 : “GN”、 “dwt”、 “carat”、 “M+” unit indication
- ▼7 : “oz” or “viss” unit indication (set as needed), or no unit indication

**Approval model: “▼” indications description:**

- ▼1 : (STABLE) stable indication
- ▼2 : (GROSS) gross weight indication
- ▼3 : ( ) unit weight insufficient indication
- ▼4 : ( PT ) pre-tare indication
- ▼5 : Range 2
- ▼6 : Range 1
- ▼7 : M+



# 1-5 Power Supply

## Power Supply Selection

- ① 6V / 4.5Ah rechargeable battery
- ② Input 110VAC or 230VAC ±15% ; Output 10VDC/1A adaptor


## Power Consumption

Approximately DC 14 mA (Indicator)  
 Approximately DC 24 mA (Indicator + Display backlight)

## Charging Voltage

DC 10V/1A output adaptor

## Low Battery Warning

Please note when the (  ) symbol keeps flashing on the display, the internal battery should be recharged.

- ☞ The scale will turn off automatically after a few hours when the low battery warning symbol shows up. The scale must be fully charged, before operating again.
- ☞ When the battery status indication is full, the power is about 6.1V; Each block is about 0.2V; When the battery warning symbol shows up, the power is about 5.4V.

# 1-6 Keypad Function

## **OFF** KEY

Press the **OFF** key to switch the indicator off.

## **ON|ZERO** KEY

- ① When the power is off, press **ON|ZERO** key to switch the indicator on.
- ② When the power is on, press **ON|ZERO** key to return to zero.
- ☞ Zero Range : OIML&NTEP is ±2% F.S., and Sri Lanka is ±3% F.S.

## **TARE|PT** KEY: Tare / Pre-tare key

### To TARE:

Place the container onto the scale, until the weight value is stable, press **TARE|PT** key for zero return and the NET indication is shown on the display. Place the object onto the container and the display shows the net weight value of the object. Remove both object and container, and negative value of the container will show on the display. Press **TARE|PT** key again to clear “tare value”. The scale returns to zero and NET indication goes off.

- ☞ Tare can be continuously done until tare value=full load capacity
- ☞ Continuous Tare → Press **TARE|PT** key for continuous weight increase/decrease on platter.
- ☞ If there is Tare, the pre-tare cannot be done. If there is pre-tare first, and the tare weight more than pre-tare weight, Tare can be done.
- ☞ No Tare can be done under gross weight display mode.

### To PRE-TARE:

Press **TARE|PT** key, use keypad to input pre-tare weight. When the cursor flashes on the rightmost digit, press **TARE|PT** key again to complete.

Pre-tare mode, keypad function as followed:

- |   |   |
|---|---|
| <b>ON ZERO</b> ⇒ upward key (0~9 digit entry) | <b>NET GROSS</b> ⇒ move cursor leftward |
| <b>UNIT</b> ⇒ downward key (0~9 digit entry)  | <b>TARE PT</b> ⇒ move cursor rightward  |



### UNIT KEY

Press the **UNIT** key to switch weight units; the display icons will indicate the active units.

### NET|GROSS KEY (Non-approval models. For approval models, use NET|B/G key instead)

In the Tare mode, the screen displays the "TARE" icon; press the **NET|GROSS** key to switch between the "Net value" and the "Gross value". When the "GROSS" arrow ▼ shows up, the Gross Weight in the screen = Tare weight + Net weight, meanwhile, keys except the **NET|GROSS** key, have no response.

### M+|PRINT KEY

Totalization function. M+/Print function is available when RS232 is on keypad transmission mode. (r 5 1 0 4 output).

This key is a composite key, while totalization is shown and weight returns to net zero, press M+ key to erase memory. RS232 will output MC print format (r 5 1 0 3 output).

☞ If there is new weight added on platter (it is less than 20 divisions in Brazil version, no accumulation), a new item will be added to totalization. If this weight is not taken off, nothing can be added to totalization. Display will show the totalization numbers for one second, then show net weight for one second, then the scale returns to the current weight, and prints out the last item for totalization.

☞ To clear totalization data, press M+ key to let display shows up totalization numbers, then press the **M+|PRINT** key again, to clear totalization data. RS232 will print out totalization numbers, total weight, etc.

P.s. Weight must return to net zero if to perform clear function.

### F KEY (Non approval models. For approval models, use F/HR key instead)

Function key (In F r 1 2, select **F** key as "MC" or "HR")

### Foot Switch Mode

This function is optional. Use F r 1 1 to select **TARE|PT** key as "ZERO" or "PRINT" key

☞ If "PRINT" key is set (r 5 1 0 3 = 10/11), all totalization data will be printed out, and totalization will be cleared.

☞ If it is Brazil version and foot switch is set as Print function, it has totalization function and print function.

### Simple Counting Mode

Use **UNIT** key to switch unit to Pcs, to go into simple counting mode.

1. Use **NET|GROSS** key (For approval models, use **NET|B/G** key instead), to select a sample number from "10, 20, 50, 100, or 200". Display will show 10, 20, 50, 100, 200 in an sequential order by pressing **NET|GROSS** key (For approval models, use **NET|B/G** key instead).

2. Select a sampling number, and put appropriate weight on platter, and press **UNIT** key. Display will show "— — — — —". The scale will go into counting mode after weight is stable, and display will show the sample number.

☞ Unit weight insufficient (Pcs): Sample unit weight is **less** than 0.2d or total sample weight is **less** than 20d (d=division)

☞ While sampling, if there is insufficient sample or unit weight insufficient indication "▼", the scale is still usable, but there may be slight inaccuracy.


☞ After Power-off, the scale automatically memorizes the sampling number, and it is available when "Pcs" unit is selected next time.

☞ If the setting is "automatic average unit weight", if the object on platter > the previous sampling number more than 5 pcs, and also < less than 100% the previous sampling number, the scale will execute unit weight calibration automatically.



## 1-7 Self-Test Mode

When power is off, hold **NET|GROSS** key (For approval models, use **NET|B/G** key instead), and press **ON|ZERO** key, Wait till display shows **01 AdC** to enter "Self-Test Mode".



### **01 AdC INTERNAL VALUE MODE** (must hook up full-bridge Load Cell to test)

- ① Press **TARE|PT** key to enter, and the display shows internal value
- ② Please check the internal value is within normal range is 0 ~ 400000 (no load)
- ③ Check whether the backlight is on
- ④ Press **ON|ZERO** key to back to the last screen, the display shows **01 AdC**

### **02 KEY KEYPAD TEST MODE**

- ① Press **TARE|PT** key to enter, display shows **KEY 06**  
Keypad's internal code: **TARE|PT** key = 06, **UNIT** key= 05, **F** key = 02  
**NET|B/G** or **NET|GROSS** key=04
- ② Press **ON|ZERO** key to back to the last screen , the display shows **02 KEY**

### **03 Ver FIRMWARE VERSION DISPLAY MODE**

- ① Press **TARE|PT** key to enter , display shows the firmware version **02005** ,
- ② Press **TARE|PT** key again, the display shows maintenance number **158** for 2 seconds
- ③ Press **ON|ZERO** key to back to the last screen, display shows **03 Ver**

### **00 ESC BACK TO THE LAST SCREEN**

Press **TARE|PT** key to exit self-test mode, the scale will re-power on automatically.



## 1-8 Error Messages

- EE0 ⇒ The EEPROM is not working correctly.  
The EEPROM is not set yet, or the circuit on PCB is broken.
- E1 ⇒ Zero is higher than the zero range when switching the indicator on.
- E2 ⇒ Zero is lower than the zero range when switching the indicator on.
- E4 ⇒ A/D value is unstable.
- OL ⇒ The weight of the object is over 9 divisions of the maximum capacity .
- OL ⇒ The weight of the object is under -1/6 maximum capacity.
- OF ⇒ ADIC value is over the maximum range.
- E10 ⇒ The scale is not in level status.  
(Only available with level detector equipped)

### Level Switch Function (Option)

Make J14 through circuit and the display will show “E 10 “, while all keys stop working in the mean time. On the other hand, make J14 short circuit to make all functions start working.

When the mercury switch of the scale is in level and stable condition, it will transmit a close circuit signal CN6 to make all functions work properly. On the other hand, when the mercury switch is not level (is tilted), it will transmit a through circuit to CN6 to make the display show “E 10“, all keys stop working.

## 1-9 Weight Units

kg	1 g = 0.001 kg
g	1 g = 1 g
lb	1 g = 0.002204623 lb
lb/oz	1 g = 0.03527396 oz
oz	1 g = 0.03527396 oz
GN	1 g = 15.432358 GN
dwt	1 g = 0.6430149 dwt
ct	1 g = 5 ct
hk.tael	1 g = 0.02645546 Hk.catty
viss	1kg = 0.612245 viss




# Chapter 2 Configurations

## Configuration Workflow

In the weighing mode, press **NET|GROSS** key (For approval models, use **NET|B/G** key instead) and **ON|ZERO** keys at the same time to enter the configuration mode. The LCD shows **01 Fnc**.

### Overall workflow of the Advanced Function setting mode:




- 01 Fnc ⇒ General Function Setting Mode
- 02 EC ⇒ External Weight Calibration
- 03 r51 ⇒ RS232 Bi-direction Function Setting
- 00 ESC ⇒ Exit the Advanced Function Setting Mode

Refer to the following sections for the detailed operation procedures of each function setting.



## 2-1 General Function Setting 01 Fnc

Workflow of the General Function setting:




Fnc 00	⇒ Return to the Advanced Function Setting Mode Menu
Fnc 01	⇒ Automatic Backlight Function Settings
Fnc 02	⇒ Automatic Power-off Timer Settings
Fnc 03	⇒ Hi/Lo/OK Settings
Fnc 04	⇒ Restore the Default Settings
Fnc 05	⇒ Noise Filter Settings
Fnc 06	⇒ Hold Function Settings
Fnc 07	⇒ Auto Unit Weight Averaging Setting
Fnc 08	⇒ Reserved
Fnc 09	⇒ Reserved
Fnc 10	⇒ Record Last Zero
Fnc 11	⇒ Foot switch on/off settings (Option)
Fnc 12	⇒ <b>F</b> key function settings
Fnc 13	⇒ Zero Setting



## 2-1-1 Auto Backlight Function Setting F<sub>n</sub>C 0 1

Select F<sub>n</sub>C 0 1 in the general function setting mode 0 1 F<sub>n</sub>C to change the backlight function setting.



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

**Auto backlight function**


When the weight is over 10d, the display backlight will be on. After the weight is stable for 10 seconds or when the scale returns to zero, the display backlight switches off.





## 2-1-2 Auto Power-off Timer Setting F<sub>n</sub>C 02

Select F<sub>n</sub>C 02 in the general function setting mode 0 | F<sub>n</sub>C to change the automatic power-off timer setting.



**Automatic power-off timer setting**  
Use **ON|ZERO** or **UNIT** key to key in parameter

- 0 ⇒ No auto power-off
- 1 ⇒ When the scale is idle for 1 minute, the scale automatically switches off
- 2 ⇒ When the scale is idle for 2 minutes, the scale automatically switches off
- ↓
- 9 ⇒ When the scale is idle for 9 minutes, the scale automatically switches off

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

**Auto power-off function**


When the weight on weigh pan is less than 10d or keeps idle for the set time, the scale will automatically switch off.



## 2-1-3 HI/LO/OK Settings F<sub>n</sub>C 03

Select F<sub>n</sub>C 03 in the general function setting mode 0 | F<sub>n</sub>C to set the HI/LO/OK function.

☞ When the high limit and low limit are both set as “0”, the Hi/Lo/OK function is disabled.




**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)



## 2-1-4 Restore to the Default Settings F<sub>n</sub>C 04

Select F<sub>n</sub>C 04 in the general function setting mode 0 : F<sub>n</sub>C to restore to the default settings.



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

☰ The defaults are included the following:

- 1) External weight calibration
- 2) HI/LO/OK setting values
- 3) Noise filter setting (External)
- 4) Sampling settings for the counting function


☰ Approval model does not have the setup access for F<sub>n</sub>C 04



## 2-1-5 Noise Filter Settings F<sub>n</sub>C 05

Select F<sub>n</sub>C 05 in the general function setting mode 0 | F<sub>n</sub>C to set the noise filter settings.

When modifying F<sub>n</sub>C 05, the parameters of [F<sub>n</sub> 0] remain un-altered.




Approval model does not have the setup access for F<sub>n</sub>C 05



## 2-1-6 Hold Function Settings F<sub>n</sub>C 06

When [F<sub>n</sub> 02] = 1 (OIML or NTEP approval), F<sub>n</sub>C 06 setting cannot be changed, and hold=0



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

hold 0 = Hold function disabled

hold 1 = “Peak hold” mode

The scale keeps displaying the maximum weight when the weight is continually changing. Press any key to exit this mode.

hold 2 = “Stable hold 1” mode

When the weight is stable, the LCD shows the current weight value. Press any key to exit this mode.

hold 3 = “Stable hold 2” mode


When the weight is stable, the LCD shows the current weight value. When the weight returns to zero (<10d), the hold mode is cancelled automatically.

hold 4 = “Animal scale hold” mode

When the scale returns back to zero, the display shows “ - - - - - ”. After the animal or object is on the platter and the scale becomes stable, the display shows the weight value and hold. Then when the animal or object is off the platter, the display shows “ - - - - - ” (or the weight is less than 10e) and the hold function is off. If the scale is hardly stable when the animal is on the platter, the scale shows the average weight in 10 seconds and holds the status.




# Hold Function Setting (Animal scale) hold 4



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)



## 2-1-7 Auto Unit Weight Averaging Setting F<sub>n</sub>C 07



**Auto unit weight averaging setting**  
LCD displays the last parameter setting

**Auto unit weight averaging setting**  
Use **ON|ZERO** or **UNIT** key to key in the parameters

- Default setting = 0
- 0 ⇒ Auto unit weight averaging
- 1 ⇒ Non auto unit weight averaging


**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)

## 2-1-8 Record Last Zero F<sub>n</sub>C 10



LCD displays the last parameter setting

### Record Last Zero

Use **ON|ZERO** or **UNIT** key to select the setting  
Default setting = **OFF**

- ≡ ON** ⇒ Record the last zero setting
- ≡ OFF** ⇒ No record

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)


**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)

**F<sub>n</sub>C 10** is only for non-approval model with **C<sub>F</sub>n 02** parameter setting.



## 2-1-9 Foot Switch Settings F<sub>n</sub>C 1 1 (Option)



**Foot switch on "ZERO" function**  
Display shows parameter from the previous setup

**Foot switch on "TARE" function**

**Foot switch on "PRINT" function**  
RS232 print out data sent from pressing **M+** key  
If it is Brazil version and r 5 1 0 4 = n PLUS, the format is r 5 1 0 3 format and it has totalization function.


- ON|ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)





## 2-1-10 **F** Key Function Settings F<sub>n</sub>C 12

(For approval models, use **F/HR** key instead)



**F** key function represents “MC” function

Display shows parameter from the previous setup

**F** key function represents “HR” function

**F** key function represents tare or pre-tare value

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)


**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

## 2-1-11 Zero Setting F<sub>n</sub>C 13



**Unrestricted zero setting off**

Display shows parameter from the previous setup. Here is:

**Unrestricted zero setting on**

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward


**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

**F<sub>n</sub>C 13** is only for non-approval model with **C<sub>F<sub>n</sub></sub> 02** parameter setting.



## 2-2 External Weight Calibration 02 EC



Press **TARE|PT** key, the display shows the calibration value. The right digit keeps flashing.  
 ☞ **The calibration value could be changed**

Press **NET|GROSS** key to move the flashing digit to the left.

When the right digit is flashing, Press **TARE|PT** key while there is no load on platter

Press **NET|GROSS** key to skip

Reading Zero

About 2 seconds later

Put the calibrated weight on platter and press **TARE|PT** key; After 3 beep sounds, calibration completes; Remove weight

Press **NET|GROSS** key to exit

About 2 seconds later


**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

☞ The conditions for external weight calibration:  
 The calibration weight value placed on the platter must be over 100e, and the standard deviation of the weight must be within 10%.

☞ 02 EC is only for non-approval models



## 2-3 RS232 Serial Interface Settings 03 r5 1




**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

- r5 1 00 ⇒ Exit the RS232 Serial Interface Setting Mode
- r5 1 01 ⇒ Baud Rate Settings
- r5 1 02 ⇒ Communication Protocol Settings
- r5 1 03 ⇒ Output Format Settings
- r5 1 04 ⇒ Transmission method setup
- r5 1 05 ⇒ The Selection of Continuous Transmission Rate
- r5 1 06 ⇒ Auto Transmission at Zero
- r5 1 07 ⇒ Reset of Auto Transmission
- r5 1 08 ⇒ Output Condition Settings
- r5 1 09 ⇒ RS232 6/7 digits setting
- r5 1 10 ⇒ RTC adjustment
- r5 1 11 ⇒ Y/M/D Print Format Selection
- r5 1 12 ⇒ RS485 ID Input (Option)
- r5 1 13 ⇒ Line Feed Input



## 2-3-1 Baud Rate Settings r 5 | 0 |

Select r 5 | 0 | in the RS232 serial interface setting mode 03 r 5 | to set the Baud Rate.



**Baud rate setting**  
 LCD displays the last value  
 ➤ Default value: 9600 (bits/sec)


**Baud rate setting**  
 Use **ON|ZERO** or **UNIT** key to select the desired Baud rate 600、1200、2400、4800、9600、19200 (bits/sec)

- ON|ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)



## 2-3-2 Communication Protocol Settings r5 1 02

Select r5 1 02 in the RS232 serial interface setting mode 03 r5 1 to set the Communication Protocol.




- ON|ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)



## 2-3-3 Output Format Settings r 5 | 03

Select r 5 | 03 in the RS232 serial interface setting mode 03 r 5 | to set the Output Format.



**RS232 output format setting**  
LCD shows the last setting.  
➤ Default setting: F-n 0

**RS232 output format setting**  
Use **ON|ZERO** or **UNIT** key to select the output format:

- F-n 0 = Same data as the scale
- F-n 1 = Gross weight
- F-n 2 = Net weight
- F-n 3 = Same data as the scale in simple format
- F-n 4 = Same gross data as the scale in simple format
- F-n 5 = Same net data as the scale in simple format
- F-n 6 = Hi/Lo/OK status + Same data as the scale in simple format
- F-n 7 = Hi/Lo/OK status + Simple gross weight
- F-n 8 = Hi/Lo/OK status + Simple net weight
- F-n 9 = Tare value
- F-n 10 = **M+** Transmission 1 note 1
- F-n 11 = **M+** Transmission 2 note 2
- F-n 12 = Brazil printing format note 3

Format 12 are only for Brazil  
Format 10.11 are not available on counting mode

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)



**Note1:**

Ticket No.

Date year/month/day & day/month/year (choose 1 out of 2 date formats)

Time

G

T

N

Total Net (This line will only print when data is erased, showing net weight total of every count)

**Note2:**

Ticket No.

Date year/month/day & day/month/year (choose 1 out of 2 date formats)

Time

G

T

N

Total Weight (This line will only print when data is erased, showing gross weight total of every count)

**Note3:**

If it is not Brazil version, it can only print under continuous transmission.

If it is Brazil version, under decimal units mode, F r C 1 1 = P r 1 1 1 and

r 5 1 0 4 = n \_ P L 0 5, it can print out. It is not available on counting mode.

For example:


70.15Kg print as: =51.07000=51.07000=51.07000=51.07000=51.07000

negative 70.15Kg print as: =51.0700-=51.0700-=51.0700-=51.0700-=51.0700-



## 2-3-4 Continuous Transmission Settings r5 | 04

Select r5 | 04 in the RS232 serial interface setting mode 03 r5 | to set the Continuous Transmission status.




**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)





## 2-3-5 Selection of the Continuous Transmission Rate r 5 1 0 5

Select r 5 1 0 5 in the RS232 serial interface setting mode 0 3 r 5 1 to set the Continuous Transmission Rate.




- ON|ZERO** key ⇒ Upward key (0~9 digit entry)
- UNIT** key ⇒ Downward key (0~9 digit entry)
- TARE|PT** key ⇒ Move cursor rightward
- NET|GROSS** key ⇒ Move cursor leftward
- (For approval models, use **NET|B/G** key instead)



## 2-3-6 Auto Transmission at Zero r 5 | 0 6

Select r 5 | 0 6 in the RS232 serial interface setting mode 0 3 r 5 | to set the Auto Transmission at Zero.




☞ When the value of "Auto transmission at zero" set as 0 - b 0 0, the "Auto transmission at zero" function is not available. Because when the scale is at zero and keeping stable, the data are keeping transmitted, and that would be the same as "Continuous Transmission".



## 2-3-7 Reset Auto Transmission $r\bar{5} | 0\bar{7}$

Select  $r\bar{5} | 0\bar{7}$  in the RS232 serial interface setting mode  $0\bar{3} | r\bar{5} |$  to Reset Auto Transmission.



☰ When the value of "Auto transmission at zero" set as  $0-b | 00$ , the "Auto transmission at zero" function is not available. Because when the scale is at zero and keeping stable, the data are keeping transmitted, and that would be the same as "Continuous Transmission".



## 2-3-8 Output Condition Settings r 5 1 0 8

Select r 5 1 0 8 in the RS232 serial interface setting mode 0 3 r 5 1 to Reset of Auto Transmission.

r 5 1 0 8

Press **TARE|PT** key

Stb-P

**Output condition settings**  
The LCD shows the last setting.

➤ Default setting: Stb-P

Use **ON|ZERO** or **UNIT** key to select the desired setting

ALL-P

**Output condition settings**  
Use **ON|ZERO** or **UNIT** key to select the desired setting:

ALL-P = All output

Stb-P = Stable output  
(No output when OL or unstable)

Press **TARE|PT** key

r 5 1 0 8

StoL-P = Stable output  
(OL included)

Key in the parameter "00"

r 5 1 0 0

Press **TARE|PT** key to exit RS232 2-way serial interface settings

0 3 r 5 1

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward


**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



## 2-3-9 RS232 6/7 Digits Setting r5 1 09

Select r5 1 09 in the RS232 serial interface setting mode 03 r5 1 to Reset of Auto Transmission.



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)




**TARE|PT** key ⇒ Move cursor rightward


**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



## 2-3-10 RTC Adjustment

Select  in the RS232 serial interface setting mode   to reset of Auto Transmission.



Enter the date in YY/MM/DD  
Use upward and downward key to select, and use **TARE|PT** key to confirm




Move cursor to the right end and Press **TARE|PT** key


Enter time in HH/MM/SS  
Use upward and downward key to select, and use **TARE|PT** key to confirm, and move rightward.

Move cursor to the right end and Press **TARE|PT** key to confirm.  
RTC adjustment is complete

- ON|ZERO** key ⇒ Upward key (0~9 digit entry)
  - UNIT** key ⇒ Downward key (0~9 digit entry)
  - TARE|PT** key ⇒ Move cursor rightward
  - NET|GROSS** key ⇒ Move cursor leftward
- (For approval models, use **NET|B/G** key instead)

## 2-3-11 Y/M/D Print Layout Selection

Select  in the RS232 serial interface setting mode   to reset of Auto Transmission.



Display shows the previous setup  
Use upward and downward key to select, and use **TARE|PT** key to confirm


If y\_m\_d, printed as Year/Month/Day  
If d\_m\_y, printed as Day/Month/Year

- ON|ZERO** key ⇒ Upward key (0~9 digit entry)
  - UNIT** key ⇒ Downward key (0~9 digit entry)
  - TARE|PT** key ⇒ Move cursor rightward
  - NET|GROSS** key ⇒ Move cursor leftward
- (For approval models, use **NET|B/G** key instead)




### 2-3-12 RS485 ID Input (Option) r 5 | 1 2

Select r 5 | 1 2 in the RS232 serial interface setting mode 0 3 | r 5 | to reset of Auto Transmission.



### 2-3-13 Line Feed Input r 5 | 1 1 3

Line feed would be available only when r 5 | 1 0 3 was set as 1 0 or 1 1.






## Chapter 3 Service Mode Access

Open the case, then switch the mini-jumper SWA1 on the main board to the ADJ position (EEPROM UNLOCKED). Turn the power on. The display shows 01 C5P.

When finished, set the jumper SWA1 back to the LOCK position.

If the jumper SWA1 is returned to the LOCK position during calibration, the machine exits the service mode automatically.

The Service Mode Access contains 6 settings as below:



01 C5P ⇒ Capacity Setup

04 CFn ⇒ Function Setting

02 CAL ⇒ Weighing Calibration


06 CGr ⇒ Local Gravity Setting

03 CLn ⇒ Linearity Calibration





### 3-1 Capacity Setup 01C5P




**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)

C5P 00 ⇒ Return to the Upper Level  
C5P 01 ⇒ Weight Units Setting  
C5P 02 ⇒ Customised Weight Units Setting  
C5P 03 ⇒ Multi-segment Setting




### 3-1-1 Weight Unit Setting [5P01

There is no resolution limitation when the weight units “kg, g, lb, lb/oz” are selected. The weight units “oz, GN, dwt, and ct” are only available on indicators with less 1/10,000 external resolution.





**NOTE 1** The users can set up the different weight units in various orders according to their preference, and the amount of the chosen weight units can be up to 5



- (a) ⇒ The first weight unit (only “kg”, “g”, or “lb” are available to choose from. Please select one of the parameters 0, 1, or 2)
- (b) ⇒ The second weight unit (select one of the parameters described below)
- (c) ⇒ The third weight unit (select one of the parameters described below)
- (d) ⇒ The fourth weight unit (select one of the parameters described below)
- (e) ⇒ The fifth weight unit (select one of the parameters described below)
- (f) ⇒ The amount of the weight units selected (select one of parameters 1 ~ 5)


The description of the parameters

0 ⇒ kg (Decimal system)	5 ⇒ oz (Decimal system)
1 ⇒ g (Decimal system)	6 ⇒ GN (Decimal system)
2 ⇒ lb (Decimal system)	7 ⇒ dwt (Decimal system)
4 ⇒ lb, oz (hexadecimal)	8 ⇒ ct (Decimal system)

For example:

Choose “kg” & “lb” (two weight units). NOTE the scale is calibrated using “kg” weights and key in 020002

**NOTE 2** Enter the maximum capacity of the scale, total 6 digits (not including 9d)




For example:

15.000 kg ⇒ key in 015000

1500.0 g ⇒ key in 015000

6.000 lb ⇒ key in 006000

**NOTE 3** Set the minimum division and decimal point position to determine the display resolution



Division =  $m * 10^{-n * q}$ , m = base value, n = numbers of decimal point, q = multiplication factor

(m) ⇒ Division base value, select 1, 2, or 5

(n) ⇒ The number of decimal places (0 ~ 5)

For example: 15.000 kg ⇒ enter 3, 1500.0 g ⇒ enter 1, 6.000 lb ⇒ enter 3

(o) ⇒ range setting (select one of parameters 0, 1, 2, or 3)

For example:

0, 1 ⇒ full segment range, 2 ⇒ 2 segment range (divided at 1/2 of the full scale),

3 ⇒ 3 segment range (divided at 1/6 of the full scale & 2/3 of the full scale)

(p) ⇒ 0 : multi-interval    1 : multi-range




**Multi interval:** Multiple segment range and each segment with its own minimum and maximum capacity and scale interval. The selection of the appropriate weighing segment is determined automatically according to the load applied, both on increasing and decreasing loads.


**Multi range:** Similar to Multi-interval, but the scale interval unchanged when unloading until weight return to zero

2 Segment range:

Multi interval




Multi range




3 Segment range:

Multi interval



Multi range



(q) ⇒ Division multiplication factor: ( Only one Weight UNITS Model is available)

0 ⇒ no factor    1 ⇒ base value X 10


Division Table for various m and q values:

(m) = 1	(m) = 2	(m) = 5	(m) = 1	(m) = 2	(m) = 5
(q) = 0			(q) = 1		
1	2	5	10	20	50

**P.S.** If 2 segment range and multi-interval is set, tare automatically cancels out after weight is cleared.



### 3-1-2 Customised Capacity Setting [ 5 P 0 2 ]



Cont



Cont

C5P 02

Press **TARE|PT** key

12.005 lb

The display shows current setting is max capacity of 12 lb with 0.005 lb/division for 2 seconds.

00000 1

Refer to "Note 5"

To setup 2<sup>nd</sup> weight unit for max capacity of 6000g with 1g/division Enter 006000 ⇒ 6000 g

006000

Press **TARE|PT** key

000002

Enter equivalent mass value 12 lb = 5443 g 005443 ⇒ 5443 g

Refer to "Note 5"

005443

For example:

1 ⇒ division base value = 1

0 ⇒ 0 decimal points ⇒ division = 1

1 ⇒ "g"

0 ⇒ full segment range

2 ⇒ save as the second selected weight unit

0 ⇒ multi-interval

Press **TARE|PT** key

000003

Refer to "Note 6"

10 1020

The display shows the 2<sup>nd</sup> weight unit has max capacity of 6000g with 1 g/division for 2 seconds.

Press **TARE|PT** key

6001 g

Set all weight units according to preference

After all weight units desired have been set

C5P 02

Input "00"

C5P 00

Press **TARE|PT** key to complete the setting

01 C5P

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)



**NOTE 4**

(a) (b)

(a) ⇒ The number of the weight units (Max: 5, key in 1 ~ 5)

(b) ⇒ The weight unit for weight calibration (choose from “kg”, “g”, “lb”, key in 0, 1, or 2)

Parameter description:

0 ⇒ kg , 1 ⇒ g , 2 ⇒ lb

**NOTE 5**

(c) (d) (e) (f) (g) (h)                      (i) (j) (k) (l) (m) (n)

**c ~ h** set the maximum capacity (6 digits)

**i ~ n** set the mass value for weight calibration (6 digits)

The maximum capacity needs to be presented based on the decimal system, and the first unit must be the calibration unit.

**For example:** How to calculate the maximum capacity and the mass value based on the different types of weight unit.

**A. Choose “kg” as the weight unit for the weight calibration**

① The first weight unit setting: 6.000 kg / 0.002 kg

⇒ Enter the maximum capacity 006000 at (c) ~ (h)

⇒ Enter the mass value 006000 at (i) ~ (n)

② Unit “lb” (hexadecimal notation system)

Calibration weight is 6kg. 0.001 kg = 0.002204623 lb

6 kg = 6×2.204623 (lb) = 13.227738 lb. Take 12 lb as the max capacity

12.000 lb / 0.08 oz (minimum division=8, decimal point position=2)

12 lb ×16 (oz) = 192.00 oz ⇒ Enter the maximum capacity 019200 at (c) ~ (h)

13.227738 lb ×16 (oz) = 211.64 oz ⇒ Enter the mass value 021164 at (i) ~ (n)

③ Unit “GN”

Calibration weight is 6kg. 0.001 kg = 15.432358GN

6kg=92594GN ⇒ Enter the calibration weight 092594 at (i) ~ (n)

The maximum capacity 100000GN ⇒ Enter the maximum capacity 100000 at (c) ~ (h)

**B. Choose “lb” (decimal notation system) as the weight unit for the weight calibration**

① The first weight unit setting: 12.000 lb / 0.005 lb (the maximum Capacity / division)

⇒ Enter the maximum capacity 012000 at (c) ~ (h)

⇒ Enter the mass value 012000 at (i) ~ (n)

② The second weight unit setting “g”

0.002204623 lb = 1 g

12 lb = 5443 g. Take 6000 g as the maximum capacity

6000 g / 2 g (the maximum Capacity / division),

⇒ Enter the maximum capacity 006000 at (c) ~ (h)

⇒ Enter the mass value 005443 at (i) ~ (n)



③ "lb/oz" (hexadecimal notation system):  
 12. 0.00 lb / 0.05 oz (the maximum Capacity / division)  
 12 lb = 12×16 (oz) = 192.00 oz  
 ⇒ Enter the maximum capacity 019200 at (c) ~ (h)  
 ⇒ Enter the mass value 019200 at (i) ~ (n)

④ "oz" :  
 Calibration weigh 12 lb = 192.00 oz ,  
 Take 200.00 oz as the maximum capacity  
 200.00 oz / 0.05 oz (the maximum Capacity / division)  
 ⇒ Enter the maximum capacity 020000 at (c) ~ (h)  
 ⇒ Enter the mass value 019200 at (i) ~ (n)

⑤ "GN" :  
 Calibration weight 12 lb, 0.002204623 lb = 15.432358 GN  
 12 lb = 84000 GN, (1 GN = 0.06479891 g)  
 84000 GN / 10 GN,  
 ⇒ Enter the maximum capacity 084000 at (c) ~ (h)  
 ⇒ Enter the mass value 084000 at (i) ~ (n)

**NOTE 6**

000003  
 (o) (p) (q) (r) (s) (t)

(o) ⇒ Minimum division setting

Parameter description:

Decimal system:

Input 1, 2, or 5 as the minimum division for the weight value

Hexadecimal notation system:

Input 1, 2, 4, or 8 as the minimum division for the weight value

(p) ⇒ Decimal point position

Parameter description:

Decimal system:

0 ⇒ 0  
 1 ⇒ 0.0  
 2 ⇒ 0.00  
 3 ⇒ 0.000  
 4 ⇒ 0.0000  
 5 ⇒ 0.00000

Hexadecimal notation system:

0 ⇒ 0.\_0  
 1 ⇒ 0.\_0.0  
 2 ⇒ 0.\_0.00  
 3 ⇒ 0.\_0.000

(q) ⇒ Weight unit displayed

Parameter	0	1	2	4	5	6	7	8
Unit	kg	g	lb	lb,oz	oz	GN	dwt	ct
Notation system	10	10	10	16	10	10	10	10
symbol	kg	g	lb	lb	Icon 7 ▼ indication	Icon 6 ▼ Indication	Icon 6 ▼ indication	Icon 6 ▼ indication





(r) ⇒ Scale change point (Input the parameter 0, 1, 2, or 3)

Parameter description:

0 ⇒ full range

1 ⇒ full range

2 ⇒ dual range (changes at 1/2 of full scale)

3 ⇒ triple range (changes at 1/6 of full scale and 2/3 of full scale)

(s) ⇒ Save the weight units at preferred slots (no more than the number of set weight units)

Parameter description:

1 ⇒ the first slot (the weight calibration unit)

2 ⇒ the second slot

3 ⇒ the third slot

4 ⇒ the fourth slot


5 ⇒ the fifth slot

(t) ⇒ 0: multi-interval    1: multi-range




# Customized Capacity Setting- How to Revise

To revise customized setting, please follow the steps below





### 3-1-3 Multi-segment Setting $\overline{C5P 03}$




By the specification setting of  $\overline{C5P 02}$ ,  $\overline{C5P 01}$  the default separation points for the 2 segments model is 1/2 full scale, and 1/6 full scale and 2/3 full scale for the 3 segments model. To change the interval point setting, please use the  $\overline{C5P 03}$  function.

When the specification settings of  $\overline{C5P 02}$  and  $\overline{C5P 01}$  have been changed, the separation points would be reset to the default setting.



### 3-2 Linearity Calibration 03 CLn

- After linearity calibration, it is necessary to re-calibrate the weight.
- Weight calibration should be included in linearity calibration.



Remove all weight from the pan,  
Press **TARE|PT** key to enter linearity  
calibration mode.

03 CLn

L0

Remove the steel weigh pan, and  
leave the plastic one, ensure the pan  
is empty, Press **TARE|PT** key to  
record the "first point".

L1 1

Apply the 1<sup>st</sup> weight for the second  
point, enter the weight factor, Press  
**TARE|PT** key to record the  
"second point"

L2 1

Add 2<sup>nd</sup> weight, enter the weight  
factor, Press **TARE|PT** key to record  
the "third point"

L3 1

Add 3<sup>rd</sup> weight, enter the factor,  
Press **TARE|PT** key to record  
the "forth point"

L8 1

Add 8<sup>th</sup> weight, enter weight  
factor, Press **TARE|PT** key to  
record the "ninth point"

03 CLn

\*Weight factor  
Refer to note below

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Enter

**NET|GROSS** key ⇒ ESC

(For approval models, use **NET|B/G** key instead)



**Weight factor**

The weight factor is a single hexadecimal number which represents the value of the next weight compared to the size of the first weight applied to the scale.

The weight factor is arranged as follows:-

- 1 = The weights are equal.
- 2 = The next weight is twice as big as the first weight
- 3 = 3 times as big as the first weight
- 4 = 4 times...
- 5 = 5 times ...
- 6 = 6 times..
- 7 = 7 times...
- 8 = 8 times...
- 9 = 9 times....
- A = 10 times...
- B = 11 times...
- C = 12 times...
- D = 13 times...
- E = 14 times...
- F = 15 times as big as the first weight

*Exampes: 30kg scale to be linearitied with the weight values shown in brackets:*

*Ex1: 30kg (10kg ,10kg ,10kg)*

Display	Key Press	Note
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 10kg on and press the Tare key
L2 1	TARE	Put 10kg on and press the Tare key
L3 1	TARE	Put 10kg on and press the Tare key
L4 1	NET/GROSS	To finish linearity adjustment (4 points linearity calibration)
03 CLn		

*Ex2: 30kg (5kg, 10kg ,10kg, 5kg)*

Display	Key Press	Note
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 5kg on and press the Tare key
L2 2	TARE	Put 10kg on and press the Tare key, 2 is the rate of L1 (10kg is 2 x 5kg, which was used in L1)
L3 2	TARE	Put 10kg on and press the Tare key
L4 1	TARE	Put 5kg on and press the Tare key
L5 1	NET/GROSS	To finish linearity adjustment (5 points linearity calibration)
03 CLn		



Ex3: 30kg (5kg, 5kg ,10kg, 10kg)

Display	Key Press	Note
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 5kg on and press the Tare key
L2 1	TARE	Put 5kg on and press the Tare key
L3 2	TARE	Put 10kg on and press the Tare key
L4 2	TARE	Put 10kg on and press the Tare key
L5 1	NET/GROSS	To finish linearity adjustment (5 points linearity calibration)
03 CLn		

Ex4: 30kg (1kg, 2kg ,5kg, 10kg, 2kg, 10kg)

Display	Key Press	Note
03 CLn	TARE	Into linearity calibration
L0	TARE	First point (zero), remove weigh pan and press the Tare key
L1 1	TARE	Put 1kg on and press the Tare key
L2 2	TARE	Put 2kg on and press the Tare key
L3 5	TARE	Put 5kg on and press the Tare key
L4 A	TARE	Put 10kg on and press the Tare key
L5 2	TARE	Put 2kg on and press the Tare key
L6 A	TARE	Put 10kg on and press the Tare key
L7 1	NET/GROSS	To finish linearity calibration (7 points linearity calibration)
03 CLn		


☞ In the process of  $L0, L1$ , press **NET|GROSS** key (For approval models, use **NET|B/G** key instead ) to abort the linearity calibration.

☞ In the process of  $L2, L3, L4, L5, L6, L7$ , or  $L8$  press **NET|GROSS** key (For approval models, use **NET|B/G** key instead ) to finish and save the 2, 3, 4, 5, 6, 7, or 8 points calibration.

☞ In the process of  $L8$ , press **TARE|PT** key to finish and save the 9 points calibration.



### 3-3 Weight Calibration 02 CAL



- CAL 00 ⇒ Return to Previous Step
- CAL 01 ⇒ Weight Calibration
- CAL 02 ⇒ Local Gravity Setting



### 3-3-1 Weight Calibration Setting CAL 01

CAL 01

Press **TARE|PT** key, the display shows the calibration value (the maximum capacity of 1<sup>st</sup> unit setting) and unit. The right digit keeps flashing.

The calibration value could be changed.

30.00 kg

When the right digit is flashing, put the platter on the scale and press **TARE|PT** key while there is no load on platter.

Centr kg

The scale is managing the data of zero point. When it becomes stable, the display shows the calibration weight.

30.00 kg

According to the calibration weight to put the weight on the platter and press **TARE|PT** key

30.00 kg

The scale is managing the data of full capacity. When it becomes stable, the beeper makes 3 "beep" sounds and the display keep flashing. Then take off the weight and press any key to exit the calibration mode.

CAL 01

Key in "00"

CAL 00

Press **TARE|PT** key to finish the setting

02 CAL

Press **NET|GROSS** key to move the flashing digit to the left.

30.00 kg

Press **NET|GROSS** key to abort zero calibration

PRSS

About 2 seconds later

Press **NET|GROSS** key to abort full capacity calibration

5PRSS

About 2 seconds later.


**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
(For approval models, use **NET|B/G** key instead)





### 3-3-2 Manufacturing Location Gravity Setting CAL 02


- The gravity value should be among the value of Equator and Polar.  
 Equator gravity  $G_E = 9.7803184558 \text{ m/sec}^2$     Polar gravity  $G_P = 9.8321772792 \text{ m/sec}^2$   
 Taipei  $\approx 9.78914 \text{ m/sec}^2$     Shanghai  $\approx 9.79423 \text{ m/sec}^2$



**ON|ZERO** key  $\Rightarrow$  Upward key (0~9 digit entry)  
**UNIT** key  $\Rightarrow$  Downward key (0~9 digit entry)  
**TARE|PT** key  $\Rightarrow$  Move cursor rightward  
**NET|GROSS** key  $\Rightarrow$  Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)



### 3-4 Local Gravity Setting 06 00 r



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

**The gravity value should be among the value of Equator and Polar.**

Acceleration of gravity at the Equator:  $G_E = 9.7803184558 \text{ m/sec}^2$


Acceleration of gravity at the Poles:  $G_P = 9.8321772792 \text{ m/sec}^2$

Taipei ⇐  $9.78914 \text{ m/sec}^2$

Shanghai ⇐  $9.79423 \text{ m/sec}^2$



### 3-5 Function Setting 04 CFn



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

- CFn 00 ⇒ Back to the upper level
- CFn 01 ⇒ Environment parameters
- CFn 02 ⇒ Approval configuration
- CFn 04 ⇒ Initial Zero Setting
- CFn 05 ⇒ Hold Function Setting
- CFn 06 ⇒ Zero Tracing Setting



### 3-5-1 Environment Parameters [Fn 01]


If parameters are changed in [Fn 01], then [Fn 05] will be revised automatically




Press [TARE|PT] key




Use [ZERO] or [UNIT] keys to enter the parameter




Press [TARE|PT] key




Use [ON|ZERO] or [UNIT] key to enter the parameter




Press [TARE|PT] key




Use [ON|ZERO] or [UNIT] key to enter the parameter




Press [TARE|PT] key



Enter "00"



Press [TARE|PT] key to exit the environment parameters



#### Return to zero

The display shows the last setting

#### Return to zero point

Using [ZERO] or [UNIT] to enter

➤ Default setting = 0

0 ⇒ show all    5 ⇒ within 5 d

1 ⇒ within 1 d    6 ⇒ within 6 d

2 ⇒ within 2 d    7 ⇒ within 7 d

3 ⇒ within 3 d    8 ⇒ within 8 d

4 ⇒ within 4 d    9 ⇒ within 9 d

Weight value must over **1/3 full scale**

#### Stabilization range

Display shows the last setting

#### Stabilization range

Use [ON|ZERO] or [UNIT] key to input the parameters.

➤ Default setting = 0

Parameter 0 ~ 9, the larger the number the more stable the weight.

#### Filter setting

Display shows the last setting.

#### Weighing Filter setting

Use [ON|ZERO] or [UNIT] key to input the parameters.

➤ Default setting = 5

Range 0 ~ 9, the larger the number, the faster the filter response. Fast response could lead to display weight instability.

Parameter 9 → the AD value is not filtered.

Input AD value = Output AD value

[ON|ZERO] key ⇒ Upward key (0~9 digit entry)

[UNIT] key ⇒ Downward key (0~9 digit entry)


[TARE|PT] key ⇒ Move cursor rightward

[NET|GROSS] key ⇒ Move cursor leftward

(For approval models, use [NET|B/G] key instead)




### 3-5-2 Approval Configuration CFn 02



☰ Brazil approved model: In the counting mode, the indicator is not able to calculate the count value if the unit weight is less than 0.1e. It will be showing "-----".



### 3-5-3 Initial Zero Setting $[CF_n 04]$



Zero range setting at switch on  
LCD displays the last setting

#### Initial Zero Setting

- Use **ON|ZERO** or **UNIT** key to enter the setting  
 Default setting = 0 (**OIML or NTEP approval model**)  
 Default setting = 9 (**Non-approval model**)
- 0 ⇒ ± 10% full scale
  - 1 ⇒ ± 20% full scale
  - 2 ⇒ ± 30% full scale
  - 3 ⇒ ± 40% full scale
  - 4 ⇒ ± 50% full scale
  - 5 ⇒ ± 60% full scale
  - 6 ⇒ ± 70% full scale
  - 7 ⇒ ± 80% full scale
  - 8 ⇒ ± 90% full scale
  - 9 ⇒ ± 100% full scale


**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)

OIML or NTEP approval model ( $[CF_n 02]$  setting is "1" ), and the initial zero setting is: ± 10% of full scale

Non-approval model ( $[CF_n 02]$  setting is "0" ), and the initial zero setting is: ± 100% full scale



### 3-5-4 Hold Function Setting [Fn] 05



**Hold function setting**  
LCD displays the last setting

**Hold function setting**

- Use **ON|ZERO** or **UNIT** key to enter parameter  
Default setting = 0
- 0 ⇒ Hold function disabled
  - 1 ⇒ “Peak hold” mode
  - 2 ⇒ “Stable hold 1” mode
  - 3 ⇒ “Stable hold 2” mode
  - 4 ⇒ “Animal scale hold” mode

**ON|ZERO** key ⇒ Upward key (0~9 digit entry)

**UNIT** key ⇒ Downward key (0~9 digit entry)

**TARE|PT** key ⇒ Move cursor rightward

**NET|GROSS** key ⇒ Move cursor leftward

(For approval models, use **NET|B/G** key instead)

**hold 0** = Hold function disabled.

**hold 1** = “**Peak hold**” mode

The scale shows the maximum weight value detected from the continuously changing weight values. Press any key to exit the hold function.

**hold 2** = “**Stable hold 1**” mode

After the scale is stable, the display shows the current weight value. Press any key to exit the hold function.

**hold 3** = “**Stable hold 2**” mode


After the scale is stable, the display shows the current weight value. Re-zero the scale (or the weight is less than 10e) to exit the hold function.

**hold 4** = “**Animal scale hold**” mode

When the scale returns back to zero, the display shows “- - - - -”. After the animal or object is on the platter and the scale becomes stable, the display shows the weight value and hold. Then when the animal or object is off the platter, the display shows “- - - - -” (or the weight is less than 10e) and the hold function is off. If the scale is hardly stable when the animal is on the platter, the scale shows the average weight in 10 seconds and holds the status.




# Hold Function Setting (Animal scale) hold 4







### 3-5-5 Zero Tracking [Fn] 05



**ON|ZERO** key ⇒ Upward key (0~9 digit entry)  
**UNIT** key ⇒ Downward key (0~9 digit entry)  
**TARE|PT** key ⇒ Move cursor rightward  
**NET|GROSS** key ⇒ Move cursor leftward  
 (For approval models, use **NET|B/G** key instead)



**☐ Burma (viss) capacity setting –Parameter reference table**

3.0000kg/0.0002kg 6.0000lb/0.0005lb 1.8000viss/0.0001viss	3.0000kg/0.0002kg 6.0000lb/0.0005lb	1.8000viss/0.0001viss
	C5P 01	C5P 02
	020002	un it30
	030000	0 18000 ⇒ <b>Max. Capacity 1.8000viss</b>
	240000	0 18367 ⇒ <b>3kg= 1.8367viss</b>
		145030
6.0000kg/0.0005kg 12.000lb/0.001lb 3.6000viss/0.0002viss	6.0000kg/0.0005kg 12.000lb/0.001lb	3.6000viss/0.0002viss
	C5P 01	C5P 02
	020002	un it30
	060000	036000 ⇒ <b>Max. Capacity 3.6000viss</b>
	540000	036734 ⇒ <b>6kg= 3.6734viss</b>
		245030
15.000kg/0.001kg 30.000lb/0.002lb 9.0000viss/0.0005viss	15.000kg/0.001kg 30.000lb/0.002lb	9.0000viss/0.0005viss
	C5P 01	C5P 02
	020002	un it30
	0 15000	090000 ⇒ <b>Max. Capacity 9.0000viss</b>
	130000	09 1836 ⇒ <b>15kg= 9.1836viss</b>
		545030
30.000kg/0.002kg 60.000lb/0.005lb 18.000viss/0.001viss	30.000kg/0.002kg 60.000lb/0.005lb	18.000viss/0.001viss
	C5P 01	C5P 02
	020002	un it30
	030000	0 18000 ⇒ <b>Max. Capacity 18.000viss</b>
	230000	0 18367 ⇒ <b>30kg= 18.367viss</b>
		135030



60.000kg/0.005kg 120.00lb/0.01lb 36.000viss/0.002viss	60.000kg/0.005kg 120.00lb/0.01lb	36.000viss/0.002viss
	CYP 01	CYP 02
	020002	un t30
	060000	036000 ⇒ <b>Max. Capacity 36.000viss</b>
	530000	036734 ⇒ <b>3kg= 36.734viss</b>
		235030
150.00kg/0.01kg 300.00lb/0.02lb 90.000viss/0.005viss	150.00kg/0.01kg 300.00lb/0.02lb	90.000viss/0.005viss
	CYP 01	CYP 02
	020002	un t30
	015000	090000 ⇒ <b>Max. Capacity 90.000viss</b>
	120000	091836 ⇒ <b>150kg= 91.836viss</b>
		535030
300.00kg/0.02kg 600.00lb/0.05lb 180.00viss/0.01viss	300.00kg/0.02kg 600.00lb/0.05lb	180.00viss/0.01viss
	CYP 01	CYP 02
	020002	un t30
	030000	018000 ⇒ <b>Max. Capacity 180.00viss</b>
	220000	018367 ⇒ <b>300kg= 183.67viss</b>
		125030
600.00kg/0.05kg 1200.0lb/0.1lb 360.00viss/0.02viss	600.00kg/0.05kg 1200.0lb/0.1lb	360.00viss/0.02viss
	CYP 01	CYP 02
	020002	un t30
	060000	036000 ⇒ <b>Max. Capacity 360.00viss</b>
	520000	036734 ⇒ <b>600kg= 367.34viss</b>
		225030



## ☞ Command Mode

### Command Format A

Host	Command
Slave	Command

MZ	Zero	SO	Command mode
MT	Tare	UA	Switch to the first unit
MG	Gross weight	UB	Switch to the second unit
MN	Net weight	UC	Switch to the third unit
CT	Clear TARE value	UD	Switch to the forth unit
SC	Continuous transmission	UE	Switch to the fifth unit
SA	Auto transmission	UF	Switch to the sixth unit
%	Stop continuous transmission and enter the command mode		

**Note:** UA ~ UF settings are depended on the model of the scale

### Command Format B

Host	Command
Slave	Data

RW	Read current weight	RH	Read Gross (simple)
RG	Read Gross weight	RI	Read Net (simple)
RN	Read Net weight	RJ	Read comparison situation + current display of weight (simple)
RT	Read TARE	RK	Read comparison situation + Gross (simple)
RB	Read current display of weight (simple)	RL	Read comparison situation + Net (simple)

**Note:** a. add % before the command to read continuously  
 b. add # before the command to transmit a stable value

### RJ,RK,RL Command Description

If RL command entered, and

if weight is higher than HI (FNC 03 setting), and if the current weight is 10 kg, the following will be displayed: "100+ 10.000"

If weight is higher than HI (FNC 03 setting), and if the current weight is 0.5 kg, the following will be displayed: "001+ 0.500"

If weight is between HI and LOW, and if the current weight is 1 kg, the following will be displayed: 010+ 1.000





## Output data format

### 1. 7 places (first decimal place not included)

#### Weight format

Gross	S	T	,	G	S	,	+	0	1	2	3	4	5	6	7	SP	SP	o	z	CR	LF		
Net	S	T	,	N	T	,	+	1	.	2	3	.	4	5	6	t	l	.	g				
Tare	S	T	,	T	R	,	+	0	1	2	.	3	4	5	6	SP	SP	k	g				
Plus OL	O	L	,	G	S	,	+	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP				
Minus OL	O	L	,	G	S	,	-	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP				
Unstable	U	S	,	G	S	,	+	0	1	2	3	4	.	5	6	SP	SP	l	b				

#### Simple format

G/N	+	1	.	2	3	.	4	5	6	CR	LF
G/N	+	0	1	2	3	4	5	.	6		
G/N	+	0	1	2	.	3	4	5	6		
Plus OL	+	SP	SP	SP	SP	SP	SP	SP	SP		
Minus OL	-	SP	SP	SP	SP	SP	SP	SP	SP		

#### Comparison status + Simple format

Byte0	Byte1	Byte2	+/-	1	.	2	3	.	4	5	6	CR	LF
-------	-------	-------	-----	---	---	---	---	---	---	---	---	----	----

Byte0 : HI 30H/31H

Byte1 : OK 30H/31H

Byte2 : LO 30H/31H

### 2. 6 places ( first decimal place not included)

#### Weight format

Gross	S	T	,	G	S	,	+	1	2	3	4	5	6	7	SP	SP	o	z	CR	LF		
Net	S	T	,	N	T	,	+	.	2	3	.	4	5	6	t	l	.	g				
Tare	S	T	,	T	R	,	+	1	2	.	3	4	5	6	SP	SP	k	g				
Plus OL	O	L	,	G	S	,	+	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP				
Minus OL	O	L	,	G	S	,	-	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP	SP				
Unstable	U	S	,	G	S	,	+	1	2	3	4	.	5	6	SP	SP	l	b				

#### Simple format

G/N	+	.	2	3	.	4	5	6	CR	LF
G/N	+	1	2	3	4	5	.	6		
G/N	+	1	2	.	3	4	5	6		
Plus OL	+	SP	SP	SP	SP	SP	SP	SP		
Minus OL	-	SP	SP	SP	SP	SP	SP	SP		

#### Comparison status + simple format

Byte0	Byte1	Byte2	+/-	.	2	3	.	4	5	6	CR	LF
-------	-------	-------	-----	---	---	---	---	---	---	---	----	----




Byte0 : HI 30H/31H

Byte1 : OK 30H/31H

Byte2 : LO 30H/31H



## Serial Data Transfer/Receive Format



Note:

S : Start bit

STOP: Stop bit

P : Parity bit



## Appendix 1 ASCII Code Table

Symbol	ASC II Code	Symbol	ASC II Code	Symbol	ASC II Code
A	41H	a	61H	0	30H
B	42H	b	62H	1	31H
C	43H	c	63H	2	32H
D	44H	d	64H	3	33H
E	45H	e	65H	4	34H
F	46H	f	66H	5	35H
G	47H	g	67H	6	36H
H	48H	h	68H	7	37H
I	49H	i	69H	8	38H
J	4AH	j	6AH	9	39H
K	4BH	k	6BH	↵	0DH
L	4CH	l	6CH		
M	4DH	m	6DH		
N	4EH	n	6EH		
O	4FH	o	6FH		
P	50H	p	70H		
Q	51H	q	71H		
R	52H	r	72H		
S	53H	s	73H		
T	54H	t	74H		
U	55H	u	75H		
V	56H	v	76H		
W	57H	w	77H		
X	58H	x	78H		
Y	59H	y	79H		
Z	5AH	z	7AH		





# Appendix 2 7-Segment Display Characters


Digit	7 segment letter	Alphabet	7 segment letter	Alphabet	7 segment letter
0		A		N	
1		B		O	
2		C		P	
3		D		Q	
4		E		R	
5		F		S	
6		G		T	
7		H		U	
8		I		V	
9		J		W	
		K		X	
		L		Y	
		M		Z	




## Appendix 3 Wiring Instructions

### Load cell wiring method

- (1) As shown below, when a load cell is connected with a 4PIN cable, SEN+ and SEN- can be unconnected. J11 and J12 on PCB must be tin-soldered in short circuit.






- (2) If Load Cell is 6PIN, please wire as the following diagram:








# RS232 wiring instruction

To connect RS232, please open the housing, RS232's PIN connectors locate on the bottom-right corner of the main board. The most common connection method is using 9PIN and 25PIN, as shown below:

PC	PIN	Function	Female 9 PINS	Function	PWH3
	2	Transmit Data		SG	
	3	Receive Data		RxD	
	5	Signal Ground		TxD	

Printer	PIN	Function	Male 25 PINS	Function	PWH3
	2	Receive Data		SG	
	3	Transmit Data		RxD	
	7	Signal Ground		TxD	

To use other connection methods, please identify the signal and following the above principles. After it is finished, please install the housing by the instruction in the *SPECIAL NOTICE*.